

Information brochure on air- and product analysis

ISSUE 2021

**DEPARTMENT OF PUBLIC HEALTH
AND PRIMARY CARE**

Environment and Health

Laboratory for
Occupational and Environmental Hygiene

CONTENTS

1. INTRODUCTION TO THE LABORATORY AND ITS ACTIVITIES	3
2. CONTACT DETAILS	3
2.1. ADDRESS	3
2.2. STAFF	3
3. GENERAL CONDITIONS	3
4. ACCREDITATIONS OF THE LABORATORY	4
5. LIST OF ANALYSES – FEES 2021	5
6. LIST OF ANALYSES OF PHARMACEUTICAL COMPOUNDS – FEES 2021	9
7. LIST OF ANALYSES CYTOSTATICS – FEES 2021	11
6. ANALYSIS VOCS DERMAL EXPOSURE – FEES 2021	11
9. LIST OF ANALYSES BIOMONITORING – FEES 2021	12
10. LIST OF MATERIALS FOR MEASUREMENTS AND OTHER SERVICES – FEES 2021	13
11. GENERAL INFORMATION REGARDING MEASUREMENT TECHNIQUES AND METHODS	15
11.1. VOC-SCREENING ASSAY FOR VOLATILE ORGANIC COMPOUNDS (VOCS)	15
11.2. DUST AND METAL ANALYSIS	16
11.3. GC-MS ANALYSIS	16
11.4. MINERAL OIL MIST ANALYSIS	16
11.5. PHARMACEUTICAL COMPOUNDS (API / IPI)	16
11.6. OTHER ANALYSES	17
11.7. DEVELOPMENT AND VALIDATION OF NEW METHODS	17
ANNEX 1: LIST OF COMPOUNDS (WITH CAS-NUMBER) DETERMINED IN VOC-ANALYSIS	18
ANNEX 2: ADDITIONAL INFORMATION CONCERNING VOC-ANALYSIS	19
ANNEX 3: PACKAGE ANALYSIS BTEXN AND/OR PACKAGE ANALYSIS VOCL - LIST OF COMPOUNDS WITH CAS-NUMBER	20
ANNEX 4: PACKAGE ANALYSIS BTEXN AND/OR PACKAGE ANALYSIS VOCL - ADDITIONAL INFORMATION	21
ANNEX 5: ANALYSIS REQUEST FORM FOR AIR- AND PRODUCT ANALYSIS	22
ANNEX 6: CLOSING DAYS OF THE LABORATORY	23

ABBREVIATIONS

ACGIH : American Conference of Governmental Industrial Hygienists
API : Active Pharmaceutical Ingredient
BTEXN : Benzene, Toluene, Ethylbenzene, Xylene, Naphtalene
ELISA : Enzyme Linked ImmunoSorbent Assay
EPA : Environmental Protection Agency
FPS ELSD : Federal Public Service Employment, Labour and Social Dialogue
GC-FID : Gas Chromatography Flame Ionisation Detection
GC-MS : Gas Chromatography Mass Spectrometry
GF : Glass Fiber
GW : Belgian Limit Values (Grenswaarde)
HDI : Hexamethylene diisocyanate
HPLC-DAD : High Performance Liquid Chromatography - Diode Array Detection
HPLC-FLD : High Performance Liquid Chromatography - Fluorescence Detection
HPLC-UV : High Performance Liquid Chromatography - Ultraviolet Detection
LC-MS : Liquid Chromatography Mass Spectrometry
ICP-MS : Inductively Coupled Plasma - Mass Spectrometry
ICP-OES : Inductively Coupled Plasma - Optical Emission Spectrometry
IOM : Institute of Occupational Medicine
IPDI : Isophorone diisocyanate
IPI : Isolated Process Intermediate
IR : Infra-red
MCE : Mixed Cellulose Ester
MDI : Diphenylmethane diisocyanate
NIOSH : National Institute for Occupational Safety and Health
OSHA : Occupational Safety & Health Administration
PAHS : Polycyclic Aromatic Hydrocarbons
PI : Phenylisocyanate
P,P' : 1-(2-Pyridyl)-Piperazine
PTFE : Polytetrafluoroethylene (Teflon)
PVC : Polyvinyl Chloride
TDI : Toluenediisocyanate
TGIC : Triglycidylisocyanurate
TLV : Threshold Limit Value
TRI : Triisocyanate
VOC : Volatile Organic Compound
VOCI : Volatile Chlorinated Organic Compound

This brochure is also available on our website:

<http://www.loeh.be>

1. INTRODUCTION TO THE LABORATORY AND ITS ACTIVITIES

The Laboratory for Occupational and Environmental Hygiene is part of the Environment and Health centre. This centre belongs to the Department of Public Health and Primary Care. The laboratory's activities involve:

- Measurements in occupational environments under the accreditation of the Belgian Federal Public Service Employment, Labour and Social Dialogue (FPS ELSD).
- Measurements in occupational and general environmental conditions and analysis of industrial components, beyond the accreditation of the FPS ELSD.
- Development and validation of new methods for measurement of (new) agents, in particular solvents and compounds which require special expertise (e.g. pharmaceutically active compounds).
- Scientific research related to environmental measurements, biomonitoring and health effects of volatile organic compounds.
- Analyses in the domain of biological exposure monitoring.

2. CONTACT DETAILS

2.1. ADDRESS

KU LEUVEN
LABORATORY FOR OCCUPATIONAL AND ENVIRONMENTAL HYGIENE
KAPUCIJNENVOER 35, 6th FLOOR – BOX 7001
3000 LEUVEN
BELGIUM

Tel: **(+32) (0)16-37.32.81**

Fax: (+32) (0)16-33.69.97

www.loeh.be

2.2. STAFF

For more information about analyses, sample material, services and quotations, you can always contact one of the following laboratory staff:

Rani Claus (rani.claus@kuleuven.be)

Peter Collaerts (peter.collaerts@kuleuven.be)

Matteo Creta (matteo.creta@kuleuven.be)

Robin Lebegge (robin.lebegge@kuleuven.be)

Mathias Merckx (mathias.merckx@kuleuven.be)

Katrien Poels (katrien.poels@kuleuven.be)

Jelle Verdonck (jelle.verdonck@kuleuven.be)

Eline Verscheure (eline.verscheure@kuleuven.be)

Karin Vranckx (karin.vranckx@kuleuven.be)

Prof. Lode Godderis, Prof. Jeroen Vanoirbeek

3. GENERAL CONDITIONS

The fees in this brochure are in Euro and exclude VAT (21%) and possible expenses for payment, for the period of **01-02-2021 to 31-01-2022**. Invoices have to be paid within 30 days.

4. ACCREDITATIONS OF THE LABORATORY

The Laboratory for Occupational and Environmental Hygiene has been granted accreditation for most of the measurements, according to Article 2 of the Belgian Royal Degree of 31st March 1992 on conditions for accreditation and according to the criteria for the equipment and operation of laboratories and services under Article 148decies 1, §6, second paragraph, of the General Regulations for Labour.

These accredited measurements include :

- Identification and determination of **187 Volatile Organic Compounds (VOCs)** including **aliphatic, aromatic and halogenated hydrocarbons, esters, ketones, glycol ethers and derivatives and alcohols** (included in NIOSH-methods 1003, 1005, 1019, 1022, 1300, 1301, 1400, 1401, 1402, 1403, 1450, 1454, 1457, 1458, 1459, 1500, 1501, 1552, 1602, 1604, 1609, 1615, 1618, 2500 en 2508) according to the PM001_VOCs method.
- Gravimetric determination of the **inhalable fraction** of dust (included in NIOSH-method 0500) with the PM004_Inhalst. method.
- Gravimetric determination of the **respirable (alveolar) fraction** of dust (included in NIOSH-method 0600) with the PM005_Inadst. method.
- Identification and determination of **isocyanate-monomers**, including **2.4-TDI, 2.6-TDI, 1.6-HDI, 4.4'-MDI, 2.4'-MDI, isophoronediiisocyanate (IPDI), phenylisocyanate (PI) and tri-isocyanate (TRI)** in the air with the PM009_Isocyanates method and PM012-Isocyanates method.
- Identification and determination of **aldehydes** in the air, including **formaldehyde, acetaldehyde, acrolein, furfural and glutaraldehyde** (included in NIOSH-method 2539) by method PM010_Aldehydes.
- Identification and determination of **ethylene oxide** in the air by method PM193_Ethylene oxide (active sampling on 2 big activated charcoal tubes in series) and PM015_Ethyleneoxide_3M (passive sampling on 3M 3551 monitor).
- Identification and determination of **methanol** in the air with the PM014_Methanol method.
- Identification and determination of **Active Pharmaceutical Ingredients (API) and Isolated Process Intermediates (IPI)** in the air and in swabs, according to more than 80 analysis methods, developed in-house and extensively validated (e.g. **Acetaminophen, Closantel, Domperidone, Elubiol, Fentanyl, Flunarizine, Fluspirilene, Haloperidol Decanoate, Imazalil, Ketanserine, Levocabastine HCl, Mebendazole, Miconazole, Oxatamide, Pimozide, Ribavirin, Rilpivirine, Sufentanil, Triamcinolone Acetonide, T1036, T2006,...**).

In view of the accreditation regulations, the laboratory continuously aims to develop high quality analysing methods, extensively validated by a prescribed protocol.

As an accredited laboratory, the Laboratory for Occupational and Environmental Hygiene maintains a quality system, as described in the European standard EN ISO/IEC 17025 "General requirements for the competence of testing and calibration laboratories".

5. LIST OF ANALYSES - FEES 2021

Component	Sampling			Analysis procedure	Fee (€) for 1 st sample	Fee (€) for 2 nd to 10 th sample	Fee (€) for > 10 th sample
	Medium	Air Flow (L/min)	Air-volume (L)				
Acetaldehyde [75-07-0]	Orbo-24 or analogue + blank	0.05	10	GC-FID	259.00	60.00	37.50
Acetic acid (C2) [64-19-7]	Activated charcoal tube (150 mg)	1.0	100	HPLC - UV	259.00	60.00	37.50
Acrolein (2-propenal) [107-02-8]	Orbo-24 or analogue + blank	0.05 – 0.2	50	GC-FID	259.00	60.00	37.50
Aldehydes (Package) Acetaldehyde [75-07-0] Acrolein (2-propenal) [107-02-8] Formaldehyde [50-00-0] Furfural [98-01-1] Glutaraldehyde [111-30-8]	Orbo-24 or analogue + blank	0.05 – 0.1	25	GC-FID	401.50	162.00	162.00
Ammonia (NH ₃) [7664-41-7]	Acid-treated silicagel tube	0.2	50	Colorimetry	259.00	60.00	37.50
Anesthesia gases (Package) Ethrane (enflurane) [13838-16-9] Fluothane (halothane) [151-67-7] Forene (isoflurane) [26675-46-7] Sevoflurane (sevorane) [28523-86-6] Desflurane (suprane) [57041-67-5]	Activated charcoal tube (150 mg)	0.1	10	GC-FID	401.50	162.00	162.00
Aniline [62-53-3]	Silicagel tube (225 mg)	0.1 – 0.2	20	GC-FID	259.00	60.00	37.50
Bromide (Br ⁻)	Orbo 53 silica geltube	0.2 – 0.5	25	Ion-specific electrode	259.00	60.00	37.50
Bromoform [75-25-2]	Activated charcoal tube (150 mg)	0.1	25	GC-FID	259.00	60.00	37.50
Butylglycidyl ether [2426-08-6]	Activated charcoal tube (150 mg)	0.05 – 0.2	10	GC-FID	259.00	60.00	37.50
Butyric acid (C4) [107-92-6]	Activated charcoal tube (150 mg)	1.0	100	HPLC – UV	259.00	60.00	37.50
Carbon disulfide (CS ₂) [75-15-0]	2 activated charcoal tubes (150 mg) in series (refrigerated shipment !)	0.05 - 0.2	10	GC-MS	259.00	60.00	37.50
Carboxylic acids (Package) Formic acid (C1) [64-18-6] Acetic acid (C2) [64-19-7] Propionic acid (C3) [79-09-4] Butyric acid (C4) [107-92-6]	Activated charcoal tube (150 mg)	1.0	100	HPLC - UV	401.50	162.00	162.00
Chloride (Cl ⁻)	Orbo 53 silica gel tube	0.2 – 0.5	25	Ion-specific electrode	259.00	60.00	37.50
Chlorine (Cl ₂) [7782-50-5]	Impigner with methyl orange solution	1.0	50	Colorimetry (within 24h)	259.00	60.00	37.50
m-Cresol (3-methylphenol)[108-39-4]	Orbo 47 tube	0.1 – 0.2	25	GC-FID	259.00	60.00	37.50
o-Cresol (2-methylphenol) [95-48-7]	Orbo 47 tube	0.1 – 0.2	25	GC-FID	259.00	60.00	37.50
p-Cresol (4-methylphenol) [106-44-5]	Orbo 47 tube	0.1 – 0.2	25	GC-FID	259.00	60.00	37.50
Cyanide (CN ⁻)	PVC-filter and bubbler with KOH solution	0.5 – 1.0	100	Ion specific electrode	259.00	60.00	37.50
Desflurane (suprane) [57041-67-5]	Activated charcoal tube (150 mg) or 3M3500 Organic Vapor Monitor	0.1	10	GC-FID	259.00	60.00	37.50
Diacetyl [431-03-8]	2 diacetyl silicagel tubes in series (SKC 226-183)	0.1	10	GC-FID	259.00	60.00	37.50
3,3'-Dichlorobenzidine [91-94-1]	GF filter and silica gel tube (225 mg)	2.0	50	HPLC-UV	259.00	60.00	37.50
Diethylene glycol monobutyl ether or (2-(2-butoxyethoxy)ethanol) (butyldiglycol) [112-34-5]	Activated charcoal tube (150 mg)	0.1	10	GC-FID	259.00	60.00	37.50
Diethylphtalate [84-66-2]	PVC filter	2.0	>10	HPLC-UV	259.00	60.00	37.50
Dimethylacetamide [127-19-5]	Silica gel tube (225 mg)	1.0	50	GC-FID	259.00	60.00	37.50
Dimethylamine [124-40-3]	Silica gel tube (225 mg)	0.1 – 1.0	3 – 30	GC-MS	259.00	60.00	37.50
Dimethylformamide [68-12-2]	Silica gel tube (225 mg)	1.0	50	GC-FID	259.00	60.00	37.50
Dimethylphtalate [131-11-3]	PVC filter	2.0	>10	HPLC-UV	259.00	60.00	37.50
Dimethylsulfoxide (DMSO) [67-68-5]	Activated charcoal tube (150 mg)	0.1	10	GC-FID	259.00	60.00	37.50
Dioclyphtalate [117-81-7]	PVC filter	2.0	>10	HPLC-UV	259.00	60.00	37.50

Component	Sampling			Analysis procedure	Fee (€) for 1 st sample	Fee (€) for 2 nd to 10 th sample	Fee (€) for > 10 th sample
	Medium	Air Flow (L/min)	Air-volume (L)				
2,4'-Diphenylmethane diisocyanate (2,4'-MDI) [5873-54-1]	GF filter impregnated with P,P'- reagent (25 or 37 mm)	2.0 or 1.0	50	HPLC-FLD	259.00	60.00	37.50
4,4'-Diphenylmethane diisocyanate (4,4'-MDI) [101-68-8]	GF filter impregnated with P,P'- reagent (25 or 37 mm)	2.0 or 1.0	50	HPLC-FLD	259.00	60.00	37.50
Dipropylene glycol monomethyl ether or (methoxypropoxypropanol) [34590-94-8]	Activated charcoal tube (150 mg)	0.1	10	GC-FID	259.00	60.00	37.50
Dust : Inhalable fraction	Pre-weighted PVC filter in IOM-cassette	2.0	200	gravimetrics	41.50	41.50	41.50
Dust : Respirable fraction	Pre-weighted PVC filter in Cyclone cassette	2.2 (HD cyclone of JS Holdings)	200	gravimetrics	41.50	41.50	41.50
Epichlorohydrine [106-89-8]	Activated charcoal tube (150 mg)	0.1 – 1.0	25	GC-FID	259.00	60.00	37.50
Ethane (enflurane) [13838-16-9]	Activated charcoal tube (150 mg)	0.1	10	GC-FID	259.00	60.00	37.50
Ethylenediamine [107-15-3]	Orbo 52 or SKC 226-48 tube	1.0	100	GC-FID	259.00	60.00	37.50
Ethylene glycol [107-21-1]	SKC 226-57 tube	0.5 – 2.0	30	GC-FID	259.00	60.00	37.50
Ethylene glycol monomethylether (2-methoxyethanol) [109-86-4]	Activated charcoal tube (150 mg)	0.1 – 1.0	10	GC-FID	259.00	60.00	37.50
Ethylene glycol monoethylether (2-ethoxyethanol) [110-80-5]	Activated charcoal tube (150 mg)	0.1 – 1.0	10	GC-FID	259.00	60.00	37.50
Ethylene glycol monobutylether (2-butoxyethanol) [111-76-2]	Activated charcoal tube (150 mg)	0.1 – 1.0	10	GC-FID	259.00	60.00	37.50
Ethylene oxide [75-21-8]	2 activated charcoal tubes (600 mg) in series	0.05	10	GC-FID	259.00	60.00	37.50
Ethylene oxide [75-21-8]	3M 3551 Organic Vapor Monitor	> 4 hours		GC-FID	259.00	60.00	37.50
Ethyl lactate [687-47-8]	Activated charcoal tube (150 mg)	0.2	10	GC-FID	259.00	60.00	37.50
Fluoride (F ⁻)	Orbo 53 silica gel tube	0.2 – 0.5	50	Ion-specific electrode	259.00	60.00	37.50
Fluothane (halothane) [151-67-7]	Activated charcoal tube (150 mg)	0.1	10	GC-FID	259.00	60.00	37.50
Forene (isoflurane) [26675-46-7]	Activated charcoal tube (150 mg)	0.1	10	GC-FID	259.00	60.00	37.50
Formaldehyde [50-00-0]	Orbo-24 or analogue + blank	0.05 – 0.2	10	GC-FID	259.00	60.00	37.50
Formic Acid (C1) [64-18-6]	Activated charcoal tube (150 mg)	1.0	100	HPLC - UV	259.00	60.00	37.50
Freon 11 (trichlorofluoromethane) [75-69-4]	Activated charcoal tube (600 mg) (refrigerated shipment !)	0.05	10	GC-FID	259.00	60.00	37.50
Freon 113 [76-13-1]	Activated charcoal tube (150 mg)	0.05	10	GC-FID	259.00	60.00	37.50
Furfural [98-01-1]	Orbo-24 or analogue + blank or Silica gel tube (225 mg)	0.05 – 0.2 0.1 – 0.5	25 25	GC-FID GC-FID	259.00	60.00	37.50
Furfuryl alcohol [98-00-0]	Silica gel tube (225 mg)	0.01- 0.05	10	GC-FID	259.00	60.00	37.50
GC-MS screening (semi-quantitative)	Activated charcoal tube (150mg) or 3M 3500 Monitor or Radiello Sampler (RAD 130)	0.05 – 1 > 4 hours > 8 hours	> 10	GC-MS	401.50 ⁽¹⁾	162.00 ⁽¹⁾	162.00 ⁽¹⁾
Glutaraldehyde (pentanedial) [111-30-8]	Orbo-24 or analogue + blank	0.05 – 0.2	25	GC-FID	259.00	60.00	37.50
1,6-Hexamethylene diisocyanate (1,6-HDI) [822-06-0]	GF filter impregnated with P,P'- reagent (25 or 37 mm)	2.0 or 1.0	50	HPLC-FLD	259.00	60.00	37.50
Hydrazine [302-01-2]	Orbo 554 or SKC 226-53 tube	0.2	100	GC-FID	259.00	60.00	37.50
Hydrobromide (HBr) [10035-10-6]	Orbo-53 silica gel tube	0.5	25	Ion-specific electrode	259.00	60.00	37.50
Hydrochloride (HCl) [7647-01-0]	Orbo-53 silica gel tube	0.5	40	Ion-specific electrode	259.00	60.00	37.50
Hydrochromate (chromic acid) [7738-94-5]	MCE filter	2.0	200	ICP-MS ICP-OES	259.00	60.00	37.50
Hydrocyanide (HCN) [74-90-8]	PVC filter and bubbler with KOH-solution	0.5 – 1.0	100	Ion-specific electrode	259.00	60.00	37.50
Hydrofluoride (HF) [7664-39-3]	Orbo-53 silica gel tube	0.5	50	Ion-specific electrode	259.00	60.00	37.50
Hydronitrate (nitric acid) [7697-37-2]	Orbo-53 silica gel tube	0.5	200	Colorimetry	259.00	60.00	37.50
Hydrophosphate (phosphoric acid) [7664-38-2]	Orbo-53 silica gel tube	0.5	200	Colorimetry	259.00	60.00	37.50

Component	Sampling			Analysis procedure	Fee (€) for 1 st sample	Fee (€) for 2 nd to 10 th sample	Fee (€) for > 10 th sample
	Medium	Air Flow (L/min)	Air-volume (L)				
Isocyanates (Package) 2.4-TDI (Toluenediisocyanate) [584-84-9] 2.6-TDI (Toluenediisocyanate) [91-08-7] 1.6-HDI (Hexamethylenediisocyanate) [822-06-0] 4.4'-MDI (Diphenylmethanediisocyanate) [101-68-8] 2.4'-MDI (Diphenylmethanediisocyanate) [5873-54-1] IPDI (Isophoronediiisocyanate) [4098-71-9] PI (Phenylisocyanate) [103-71-9] TRI (Tri-isocyanate) [-]	GF filter impregnated with P,P'- reagent (25 or 37 mm)	2.0 or 1.0	50	HPLC-FLD			
1 compound					259.00	60.00	37.50
2 compounds					290.50	92.50	70.50
3 compounds					322.50	124.50	102.00
4 compounds					354.50	156.00	133.50
5 compounds					386.50	187.50	165.00
6 compounds					418.00	219.50	197.50
7 compounds					450.00	251.50	229.50
8 compounds					482.00	283.50	261.00
Isophorone diisocyanate (IPDI) [4098-71-9]	GF filter impregnated with P,P'- reagent (25 or 37 mm)	2.0 or 1.0	50	HPLC-FLD	259.00	60.00	37.50
Metals : Aluminium (Al), Antimony (Sb), Arsenic (As), Barium (Ba), Beryllium (Be), Bismuth (Bi), Cadmium (Cd), Calcium (Ca), Chromium (Cr), Cobalt (Co), Germanium (Ge), Iron (Fe), Indium (In), Potassium (K), Copper (Cu), Lanthanum (La), Lithium (Li), Lead (Pb), Magnesium (Mg), Manganese (Mn), Molybdenum (Mo), Sodium (Na), Nickel (Ni), Selenium (Se), Strontium (Sr), Thallium (Tl), Tin (Sn), Titanium (Ti), Vanadium (V), Tungsten (W), Silver (Ag), Zinc (Zn)	MCE filter in IOM-cassette (on inhalable fraction of dust) or MCE filter in cyclone cassette (on respirable fraction of dust)	2.0	200	ICP-MS ICP-OES	49.50 (1 st metal)	49.50 (1 st metal)	49.50 (1 st metal)
		2.2 (HD cyclone of JS Holdings)	200	ICP-MS ICP-OES	32.00 (2 nd metal on the same sample)	32.00 (2 nd metal on the same sample)	32.00 (2 nd metal on the same sample)
Methanol [67-56-1]	2 big silica gel tubes (450 mg) in series	0.1 – 0.2	10	GC-FID	259.00	60.00	37.50
Mineral oil mist [8012-95-1] exploratory research of oil, inclusive report (once per oil)				GC-FID	369.00 (per oil)	-	-
Mineral oil mist and – vapour [8012-95-1]	GF-filter and activated charcoal tube in series	1.0	200	GC-FID	259.00	60.00	37.50
Mouse Urine Protein (MUP)	PTFE filter (1 µm) in IOM-cassette	2.0	960	ELISA	259.00	60.00	37.50
Nicotine [54-11-5]	Nicotine tube (Orbo 613) (refrigerated shipment 1)	0.1 - 1	10	GC-MS	259.00	60.00	37.50
PAHs (Polycyclic Aromatic hydrocarbons) : acenaphtene, acenaphtylene, anthracene, benz[a]anthracene, benzo[b]fluoranthene, benzo[k]fluoranthene, benzo[ghi]perylene, benzo[a]pyrene, chrysene, dibenz[a,h]anthracene, fenantrene, fluoranthene, fluorene, indeno[1,2,3-cd]pyrene, naphtalene, pyrene	PTFE filter and Orbo 43 tube in series	1.0 - 2.0	> 200	GC-MS	259.00	60.00	37.50
Pentachlorophenol [87-86-5]	2 Orbo 47 tubes, GF filter	0.1 – 1.0	50	HPLC-UV	259.00	60.00	37.50
Phenol [108-95-2]	Orbo 47 tube	0.1 – 0.2	25	GC-FID	259.00	60.00	37.50
Phenols (Package) Phenol [108-95-2] m-Cresol (3-methylphenol) [108-39-4] o-Cresol (2-methylphenol) [95-48-7] p-Cresol (4-methylphenol) [106-44-5]	Orbo 47 tube	0.1 – 0.2	25	GC-FID	401.50	162.00	162.00
Phenylisocyanate (PI) [103-71-9]	GF filter impregnated with P,P'-reagent (25 or 37 mm)	2.0 or 1.0	50	HPLC-FLD	259.00	60.00	37.50
Phosphorus trichloride [7719-12-2]	Bubbler with water	0.05 – 0.2	50	Colorimetry	259.00	60.00	37.50
Phthalic acid anhydride [85-44-9]	PVC filter	2.0	100	HPLC-UV	259.00	60.00	37.50

Component	Sampling			Analysis procedure	Fee (€) for 1 st sample	Fee (€) for 2 nd to 10 th sample	Fee (€) for > 10 th sample
	Medium	Air Flow (L/min)	Air-volume (L)				
Potassium hydroxide (KOH) [1310-58-3]	Impigner with HCl-solution (0.01N)	1.0	100	ICP-MS ICP-OES	49.50	32.00	32.00
Propionic Acid (C3) [79-09-4]	Activated charcoal tube (150 mg)	1.0	100	HPLC - UV	259.00	60.00	37.50
Propylbromide (1-bromopropane) [106-94-5]	Activated charcoal tube (150 mg)	0.05 – 0.2	> 10	GC-FID	259.00	60.00	37.50
Propyleneglycol [57-55-6]	SKC 226-57 tube	0.5 – 2.0	30	GC-FID	259.00	60.00	37.50
1,2-Propyleneoxide [75-56-9]	2 activated charcoal tubes (150 mg) in series (refrigerated shipment!)	0.05 – 0.2	10	GC-FID	259.00	60.00	37.50
Pyridine [110-86-1]	Activated charcoal tube (150 mg)	0.1 – 1.0	10	GC-FID	259.00	60.00	37.50
Rat Urine Protein (RUP)	PTFE filter (1 µm) in IOM-cassette	2.0	960	ELISA	259.00	60.00	37.50
Sevoflurane (sevorane) [28523-86-6]	Activated charcoal tube (150 mg) or 3M 3500 Monitor	0.1 > 4 hours	10	GC-FID	259.00	60.00	37.50
Sodium hydroxide (NaOH) [1310-73-2]	Impigner with HCl-solution (0.01N)	1.0	100	ICP-MS ICP-OES	49.50	32.00	32.00
2,4-Toluenediisocyanate (2,4-TDI) [584-84-9]	GF filter impregnated with P,P'- reagent (25 or 37 mm)	2.0 or 1.0	50	HPLC-FLD	259.00	60.00	37.50
2,6-Toluenediisocyanate (2,6-TDI) [91-08-7]	GF filter impregnated with P,P'- reagent (25 or 37 mm)	2.0 or 1.0	50	HPLC-FLD	259.00	60.00	37.50
Total hydrocarbon content, supplementary to the VOC-analysis	Activated charcoal tube (150 mg) or 3M 3500 Organic Vapor Monitor			GC-FID	21.00	21.00	21.00
Tributyl phosphate [126-73-8]	MCE filter, possibly 2x	2.0	100	GC-FID	259.00	60.00	37.50
Tri-isocyanate (TRI) [-]	GF filter impregnated with P,P'- reagent (25 or 37 mm)	2.0 or 1.0	50	HPLC-FLD	259.00	60.00	37.50
Triglycidyl Isocyanurate (TGIC) [2451-62-9]	Silanised GF filter in IOM-cassette	2.0	240	HPLC-UV	259.00	60.00	37.50
Vinylchloride [75-01-4]	2 activated charcoal tubes (150 mg) in series (refrigerated shipment!)	0.05	10	GC-FID	259.00	60.00	37.50
<p style="text-align: center;">VOC-analysis (188 compounds : see Annex 1,2)</p> <p style="text-align: center;">BTEXN package-analysis (7 compounds : see Annex 3,4)</p> <p style="text-align: center;">VOC1 package-analysis (11 compounds : see Annex 3,4)</p>							
Industrial environment (mg/m ³)	Activated charcoal tube (150 or 600 mg) or 3M 3500 organic vapor monitor	0.05 – 0.2 > 4 hours	> 10	GC-FID GC-FID	87.50 60.00	87.50 60.00	87.50 60.00
Environmental or background air sample (µg/m ³)	Activated charcoal tube (150 or 600 mg) or 3M 3500 organic vapor monitor or Radiello Sampler (RAD 130)	1.0 > 4 hours > 8 hours	>100	GC-FID GC-FID GC-FID	120.00 87.50 87.50	120.00 87.50 87.50	120.00 87.50 87.50
	Air sample, delivered in synthetic bag (qualitative reporting)			GC-FID	120.00	120.00	120.00
	Mix of solvents or organic products (% w/v - % w/w)			GC-FID	87.50	87.50	87.50
	Aqueous sample (qualitative reporting) - identification			GC-FID	87.50	87.50	87.50
	Aqueous sample (semi-quantitative reporting % w/v) – per compound			GC-FID	259.00	60.00	37.50

⁽¹⁾ On condition that composition and type of the samples are the same as those of the first sample

6. LIST OF ANALYSES OF PHARMACEUTICAL COMPOUNDS – FEES 2021

API / IPI	Sampling		Analysis procedure	Fee (€) for 1 st sample	Fee (€) for 2 nd to 10 th sample	Fee (€) for > 10 th sample
	Filter type *	Air flow (L/min)				
Abiraterone Acetate	Teflon filter (5 µm) (<u>refrigerated shipment !</u>)	2.0	LC-MS	518.00	120.50	75.50
Acetaminophen	Teflon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50
Acetaminophen (Paracetamol) (as surrogate for eg. containment tests)	Teflon filter (5 µm) (<u>refrigerated shipment !</u>)	2.0	LC-MS	518.00	120.50	75.50
Alfentanil / Alfentanil HCl	GF filter Wipe sample	2.0 -	GC-MS	518.00 259.00	120.50 60.00	75.50 37.50
Aprocitentan	GF filter (<u>samples should be protected from light after sampling</u>)	2.0	LC-MS	518.00	120.50	75.50
Azaconazole (Rodewod)	GF filter	2.0	GC-MS	518.00	120.50	75.50
Azaperone	GF filter	2.0	GC-MS	518.00	120.50	75.50
Bromperidol	GF filter	2.0	GC-MS	518.00	120.50	75.50
Bromperidol Decanoate	Teflon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
Buprenorphine	GF filter	2.0	HPLC-DAD	518.00	120.50	75.50
Capsid	GF filter	2.0	LC-MS	518.00	120.50	75.50
Ceftibiprole Medocaril (BAL5788)	Teflon filter (5 µm) (<u>refrigerated shipment !</u>)	2.0	HPLC-DAD	518.00	120.50	75.50
Cinnarizine	Nylon filter (5 µm)	2.0	GC-MS	518.00	120.50	75.50
Cisapride	Teflon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50
Clazuril	Teflon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
Clonixin	Teflon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50
Closantel	Teflon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50
Closantel Sodium	Teflon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50
Decitabine (Dacogen)	Teflon filter (5 µm) (<u>refrigerated shipment !</u>)	2.0	LC-MS	518.00	120.50	75.50
Diclazuril	GF filter	2.0	HPLC-DAD	518.00	120.50	75.50
Domperidone	Acid coated GF filter	2.0	HPLC-DAD	518.00	120.50	75.50
Elubiol	Teflon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50
Etomidate / Etomidate HCl	Nylon filter (5 µm)	2.0	GC-MS	518.00	120.50	75.50
Factor Xla (BMS-177)	Nylon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
Fentanyl / Fentanyl Citrate	GF filter Wipe sample	2.0 -	GC-MS	518.00 259.00	120.50 60.00	75.50 37.50
Flubendazole	GF filter	2.0	HPLC-DAD	518.00	120.50	75.50
FGFRI (Erdafitinib)	PVC filter (with support pad)	2.0	LC-MS	518.00	120.50	75.50
Flunarizine HCl	Teflon filter (5 µm)	2.0	GC-MS	518.00	120.50	75.50
Fluspirilene	Teflon filter (5 µm) (<u>refrigerated shipment !</u>)	2.0	LC-MS	518.00	120.50	75.50
Gainer (ARN509) (Apalutamide)	Teflon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
Galantamine HBr	GF filter	2.0	GC-MS	518.00	120.50	75.50
Haloperidol	GF filter	2.0	GC-MS	518.00	120.50	75.50
Haloperidol Decanoate	Teflon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
Ibuprofen	Teflon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50
Imazalil (Enilconazole)	Teflon filter (5 µm) (<u>refrigerated shipment !</u>)	2.0	HPLC-DAD	518.00	120.50	75.50
Imazalil sulfate (Enilconazole sulfate)	Teflon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50
Isoconazole	GF filter	2.0	LC-MS	518.00	120.50	75.50
Isoconazole Nitrate	GF filter	2.0	LC-MS	518.00	120.50	75.50
Itraconazole	GF filter	2.0	HPLC-DAD	518.00	120.50	75.50
Ketanserin	GF filter	2.0	HPLC-DAD	518.00	120.50	75.50
Ketanserin Tartrate	Teflon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
Ketoconazole	Teflon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50

API / IPI	Sampling		Analysis procedure	Fee (€) for 1 st sample	Fee (€) for 2 nd to 10 th sample	Fee (€) for > 10 th sample
	Filter type *	Air flow (L/min)				
Lazertinib	Teflon filter (1 µm)	2.0	LC-MS	518.00	120.50	75.50
Levocabastine HCl	GF filter	2.0	GC-MS	518.00	120.50	75.50
Loperamide HCl	GF filter	2.0	HPLC-DAD	518.00	120.50	75.50
Loperamide Oxide	Teflon filter (5 µm) (<u>refrigerated shipment !</u>)	2.0	HPLC-DAD	518.00	120.50	75.50
Macitentan (Opsumit)	Teflon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
Mebendazole	Teflon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
Miconazole	GF filter	2.0	LC-MS	518.00	120.50	75.50
Miconazole Nitrate	GF filter	2.0	HPLC-DAD	518.00	120.50	75.50
Mitratapid	Teflon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
Nebivolol HCl	Nylon filter (5 µm)	2.0	HPLC-FLD	518.00	120.50	75.50
Orexin -2 (Seltorexant)	PVC filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
Oxatamide	Teflon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50
Oxatamide Hydrate	Teflon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50
Paliperidone	Teflon filter (5 µm) (<u>refrigerated shipment !</u>)	2.0	LC-MS	518.00	120.50	75.50
Paliperidone Palmitate	Polypropylene filter (0.45 µm)	2.0	LC-MS	518.00	120.50	75.50
Parconazole HCl	GF filter	2.0	LC-MS	518.00	120.50	75.50
Pimozide	GF filter	2.0	HPLC-FLD	518.00	120.50	75.50
Pipamperone HCl	Teflon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
Piritramide	Teflon filter (5 µm)	2.0	GC-MS	518.00	120.50	75.50
Prasterone Acetate (T8506)	Teflon filter (5 µm)	2.0	GC-MS	518.00	120.50	75.50
Prednisolone	Teflon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
Prednisolone Acetate	GF filter (<u>refrigerated shipment !</u>)	2.0	HPLC-DAD	518.00	120.50	75.50
Prucalopride Succinate	GF filter	2.0	HPLC-DAD	518.00	120.50	75.50
Ribavirin	GF filter	2.0	HPLC-DAD	518.00	120.50	75.50
Rilpivirine (TMC 278)	GF filter	2.0	LC-MS	518.00	120.50	75.50
Rilpivirine HCl	GF filter	2.0	LC-MS	518.00	120.50	75.50
Risperidone	Nylon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50
RORgT	Teflon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
Screening for the presence of (active) components	Wipe sample	-	GC-MS	259.00	60.00	37.50
Selexipag	Nylon filter (5µm) (<u>samples should be submitted to the laboratory as soon as possible</u>)	2.0	LC-MS	518.00	120.50	75.50
SGLT2 (Canagliflozin)	GF filter	2.0	HPLC-DAD	518.00	120.50	75.50
Sufentanil / Sufentanil Citrate	GF filter Wipe sample	2.0 -	GC-MS	518.00 259.00	120.50 60.00	75.50 37.50
T1036	Teflon filter (5 µm) (<u>refrigerated shipment !</u>)	2.0	GC-MS	518.00	120.50	75.50
T1202	Teflon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
T1250	Teflon filter (5 µm) (<u>refrigerated shipment !</u>)	2.0	LC-MS	518.00	120.50	75.50
T1333	GF filter	2.0	LC-MS	518.00	120.50	75.50
T1345	Teflon filter (5 µm) (<u>refrigerated shipment !</u>)	2.0	LC-MS	518.00	120.50	75.50
T1484	Teflon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
T2006	Teflon filter (5 µm) (<u>refrigerated shipment !</u>)	2.0	LC-MS	518.00	120.50	75.50
T2019	Nylon filter (5 µm)	2.0	GC-MS	518.00	120.50	75.50
T2026	Nylon filter (5 µm) (<u>refrigerated shipment !</u>)	2.0	GC-MS	518.00	120.50	75.50

API / IPI	Sampling		Analysis procedure	Fee (€) for 1 st sample	Fee (€) for 2 nd to 10 th sample	Fee (€) for > 10 th sample
	Filter type *	Air flow (L/min)				
T2632	PVC filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
T2713	Teflon filter (5 µm) (<u>refrigerated shipment !</u>)	2.0	LC-MS	518.00	120.50	75.50
T2947	GF filter	2.0	LC-MS	518.00	120.50	75.50
T824	GF filter	2.0	GC-MS	518.00	120.50	75.50
Telaprevir (Vertex)	Teflon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50
Tetrahydrozoline HCl	Teflon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
TIC1097	Nylon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50
Tipifamib (Triple 7)	GF filter	2.0	HPLC-DAD	518.00	120.50	75.50
TMC114 Ethanolate (Darunavir)	Teflon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50
TMC125 (Etravirine)	GF filter	2.0	HPLC-DAD	518.00	120.50	75.50
TMC207 (Bedaquiline)	Teflon filter (5 µm)	2.0	LC-MS	518.00	120.50	75.50
TMC435350 (Orange)	Teflon filter (5 µm)	2.0	HPLC-DAD	518.00	120.50	75.50
Triamcinolone Acetonide	GF filter (<u>refrigerated shipment !</u>)	2.0	LC-MS	518.00	120.50	75.50
Velcade (Bortezomib)	Teflon filter (5 µm) (filters have to be desorbed immediately after sampling)	2.0	LC-MS	518.00	120.50	75.50

* For air sampling of APIs and IPIs, an IOM-sampler with an IOM-cassette (25 mm) needs to be used. Please use the correct filter type. The filter as well as the IOM grid and the shipment cover (cap) are separately extracted and analysed at the laboratory.

API / IPI	DIS (Disposable Inhalable Sampler) **	2.0		259.00	60.00	37.50
-----------	---------------------------------------	-----	--	--------	-------	-------

** For air sampling of APIs and IPIs, alternatively a DIS (Disposable Inhalable Sampler) (25 mm) can be used (if desired), provided with the correct filter type and suitable for single use only.

7. LIST OF ANALYSES CYTOSTATICS – FEES 2021

Component	Medium	Analysis procedure	Fee (€) for 1 st sample	Fee (€) for 2 nd to 10 th sample	Fee (€) for > 10 th sample
Cyclophosphamide	Cytostatics sampling kit (wipe-stick, template and vial)	LC-MS	259.00	60.00	60.00
Etoposide	Cytostatics sampling kit (wipe-stick, template and vial)	LC-MS	259.00	60.00	60.00
5-Fluorouracil (5-FU)	Cytostatics sampling kit (wipe-stick, template and vial)	LC-MS	259.00	60.00	60.00
Iphosphamide	Cytostatics sampling kit (wipe-stick, template and vial)	LC-MS	259.00	60.00	60.00
Oxaliplatin	Cytostatics sampling kit (wipe-stick, template and vial)	LC-MS	259.00	60.00	60.00

8. ANALYSIS VOCS DERMAL EXPOSURE – FEES 2021

Component	Medium	Analysis procedure	Fee (€) for 1 st sample	Fee (€) for 2 nd to 10 th sample	Fee (€) for > 10 th sample
VOC-analysis (188 compounds : see Annex 1,2) Evaluation dermal exposure (µg/patch)	Dermal patch (activated charcoal)	GC-FID	120.00	120.00	120.00

9. LIST OF ANALYSES BIOMONITORING – FEES 2021

Analysis in urine	Fee (€) per sample	Exposure to
Acetone	14.90	Acetone, Isopropanol
Aluminum (Al)	35.40	Aluminum (Al)
p-Aminophenol	13.84	Aniline
Antimony (Sb)	34.44	Antimony (Sb)
Inorganic Arsenic (As)	29.87	Arsenic (As)
Arsenic (As)	29.87	Arsenic (As)
Barium (Ba)	45.26	Barium (Ba)
Beryllium (Be)	37.63	Beryllium (Be)
Bismuth (Bi)	45.26	Bismuth (Bi)
Butanol	14.90	Butanol
Butoxy acetic acid	22.38	2-Butoxyethanol (butyl cellosolve)
Cadmium (Cd)	32.79	Cadmium (Cd)
Chromium (Cr)	32.21	Chromium (Cr)
Cobalt (Co)	32.21	Cobalt (Co)
Copper (Cu)	18.20	Copper (Cu)
Cotinine	259.00 (1 st sample) 60.00 (2 nd to 10 th sample) 37.50 (> 10 th sample)	Nicotine
Creatinine	3.34	-
o-Cresol	65.25	Toluene
Cyclohexanol	70.23	Cyclohexane
Cyclophosphamide	259.00 (1 st sample) 60.00 (2 nd to 10 th sample) 37.50 (> 10 th sample)	Cyclophosphamide
d-Ala	33.06	Lead
Dimethylbenzoic acids	54.91	Trimethylbenzenes
Ethanol	27.74	Ethanol
Ethoxy acetic acid	22.38	2-Ethoxyethanol (ethyl cellosolve)
Ethyl acetate	14.90	Ethyl acetate
Fentanyl	259.00 (1 st sample) 60.00 (2 nd to 10 th sample) 37.50 (> 10 th sample)	Fentanyl
Fluor (F)	11.11	Fluorides (F)
Formic acid	14.90	Methanol, Aceton, Formaldehyde
2,5-Hexanedione	23.96	Hexane
2-Hexanol	14.90	Hexane
Hippuric acid	11.11	Toluene
1-Hydroxypyrene	40.70	PAHs (Polycyclic Aromatic Hydrocarbons)
Isopropanol	14.90	Isopropanol
Lead (Pb)	22.27	Lead (Pb)
Mandelic acid	11.11	Styrene, Ethylbenzene
Manganese (Mn)	32.21	Manganese (Mn)
Mercury (Hg)	28.50	Inorganic mercury (Hg)
Methanol	24.46	Methanol
Methoxy acetic acid	22.38	2-Methoxyethanol (methyl cellosolve)
1-Methoxy-2-propanol	25.50	1-Methoxy-2-propanol
S-Methylcysteine	28.50	Methylbromide, Methylchloride

Analysis in urine	Fee (€) per sample	Exposure to
Methylenedianiline (MDA)	33.54	Methylenedianiline (MDA), Methylene diphenyl diisocyanate (MDI)
Methylethylketone	21.92	Methylethylketone
N-Methylformamide	22.44	Dimethylformamide
Methylhippuric acid	11.11	Xylene
Molybdenum (Mb)	33.06	Molybdenum (Mb)
Muconic acid	22.38	Benzene
Nickel (Ni)	28.50	Nickel (Ni)
Oxalic acid	33.06	Ethylene glycol
Phenol	11.11	Phenol
Phenylglyoxylic acid	27.54	Styrene
S-Phenylmercapturic acid (SPMA)	68.85	Benzene
Phenylpropanol	17.33	Isopropylbenzene
Phosphor (P)	6.66	Phosphor (P)
Selenium (Se)	30.14	Selenium (Se)
Sevoflurane	259.00 (1 st sample) 60.00 (2 nd to 10 th sample) 37.50 (> 10 th sample)	Sevoflurane
TCA (trichloro acetic acid)	27.59	Trichloroethylene
TCE (trichloroethanol)	27.59	Trichloroethylene
Tetrahydrofuran	27.62	Tetrahydrofuran
Thallium (Tl)	32.21	Thallium (Tl)
Thiocyanate	14.90	Cyanides, aliphatic nitriles
Thiodiglycolic acid	41.62	Vinylchloride
TTCA (2-Thioxothiazolidine-4-carboxylic acid)	33.22	CS ₂ (carbendisulfide)
Tin (Sn)	40.82	Tin (Sn)
Toluene diamine (TDA)	34.12	Toluene diisocyanate (TDI)
Vanadium (V)	32.21	Vanadium (V)
Zinc (Zn)	16.01	Zinc (Zn)

10. LIST OF MATERIALS FOR MEASUREMENTS AND OTHER SERVICES – FEES 2021

PUMPS	Fee (€)
Rent fee per pump per day (including calibration before and after)	32.50*
Rent fee per pump per day (including calibration before and after), without subsequent analysis	98.00*
Calibration client pump	18.00

* If a reservation is cancelled, less than 3 days before the agreed lease date, a fee for a 1 day lease will be charged.

TUBES	Fee (€)
Activated charcoal tube 150 mg (SKC 226-01), Lot 2000	2.00
Activated charcoal tube 600 mg (SKC 226-09), Lot 2000	4.70
Aldehyde tube (Orbo 24 or analogue)	8.00
Inorganic acid tube (Orbo 53)	4.70
Diacetyl silicagel tubes (SKC 226-183) (per set of 2)	6.00
Ethylene diamine tube (Orbo 52)	4.70
Ethylene glycol tube (SKC 226-57)	32.00

TUBES	Fee (€)
Hydrazine tube (Orbo 554)	5.30
Nicotine tube (Orbo 613)	3.00
PAH tube (Orbo 43)	5.50
Phenol tube (Orbo 47)	4.50
Silicagel tube 225 mg (SKC 226-10)	3.20
Silicagel tube 450 mg (SKC 226-10-04)	6.00
Acid-treated silicagel tube (SKC 226-10-06)	7.50
Tubeholder A (small tubes)	35.00
Tubeholder B (big tubes)	40.00

PASSIVE MONITORS	Fee (€)
3M 3500 Organic Vapor Monitor	22.00
3M 3551 Organic Vapor Monitor (ethyleneoxide)	35.00
3M 3520 Organic Vapor Monitor	35.00
Radiello sampler (RAD130) + Radiello diffusive body (RAD120)	23.00

FILTERS	Fee (€)
Glass Fiber Filter for IOM-cassette (25 mm)	0.80
GF filter impregnated with P,P'-reagent (25 or 37 mm) (isocyanates)	4.00
MCE-filter for IOM-cassette (25 mm)	2.10
Nylon-filter for IOM-cassette (25 mm)	2.00
Polypropylene filter (0.45 µm) for IOM-cassette (25 mm)	5.00
PVC-filter for IOM or cyclone cassette (25 mm)	4.50
Teflon (PTFE)-filter for IOM-cassette (25 mm)	4.50
Silanised GF filter for IOM-cassette (25 mm)	5.80
Acid-coated GF-filter for IOM-cassette (25 mm)	4.00

CASSETTES	Fee (€)
IOM-cassette (25 mm) (without filter)	6.00
Cyclone-cassette (25 mm) (without filter)	12.00
Three-piece cassette (37mm) (without filter) (isocyanates)	4.00
DIS (Disposable Inhalable Sampler) (25 mm) (without filter)	20.00

OTHER	Fee (€)
Dermal patch (activated charcoal) for skin exposure	4.50
Cytostatics sampling kit (wipe-stick, template and vial)	10.00
TLV-booklet (ACGIH)	60.00
Measurement on-site, per half day (shipment costs not included)	430.00
Consultancy fee per hour	107.50

Sampling equipment that will be used for analysis in the laboratory will be delivered at cost price or leased at a cost per day by a fee per day. If **activated charcoal tubes** are used, the tubes delivered by the laboratory are preferred, because these have been tested per lot on e.g. adsorption and desorption properties. Using these tubes guarantees accurate quantitative results. **Filters** (25 mm) are always

delivered in **IOM-cassettes** or **cyclone-cassettes**. These cassettes are charged as well. **IOM-samplers** and **cyclones** are leased for free, provided they will be returned to the laboratory within the agreed period and provided samples are delivered to the laboratory for analysis. Extra costs will be charged if material needs to be delivered by a courier. Prices of sampling equipment can change without preceding notification. For measurements on-site, calibration of pumps or other services concerning occupational hygiene measurements, please contact the laboratory.

11. GENERAL INFORMATION REGARDING MEASUREMENT TECHNIQUES AND METHODS

11.1. VOC-SCREENING ASSAY FOR VOLATILE ORGANIC COMPOUNDS (VOCS)

The screening assay for volatile organic compounds (VOC) is aimed at detection, identification and quantification of organic solvents in air samples taken on activated charcoal (air-pumped tube, passive diffusion type monitor) or in solvent mixtures and viscous samples (e.g. ink, paint, coating, glue, varnish). A list of compounds that can be analyzed in this screening assay is presented in **Annex 1**. Each individual sample is assayed systematically for the presence or absence of the compounds listed in **Annex 1**. For air-pumped activated charcoal tubes, both individual sections of each tube are analyzed separately. All identified compounds are subsequently quantified, provided that all essential calculation factors are available. Additional compounds (not listed in **Annex 1**) detected in the samples during the assay will be reported as non-identified compounds.

Optimum air pump flow and sampling time to be applied for this measurement procedure on the one hand depend on the nature of the expected contaminants and their anticipated airborne concentrations, as well as on general environmental conditions (e.g. relative humidity). On the other hand, air sampling should be performed during a period which is representative of the worker's exposure pattern. When sampling is performed using a passive diffusion type monitor, a minimum air sampling period of 4 hours is recommended. For samples taken with the pumped activated charcoal tube procedure, a minimum air volume of 10L is generally required. For sampling very volatile organic compounds, exceptionally, either a shorter duration of sampling or a limited volume of sampled air is recommended (see also **Annex 1**). For long-term measurements (4 tot 8 hours) a pump flow of 50-200 ml/min is generally adequate, while for short-term and peak sampling (15 min) an air flow of 1 L/min is commonly applied.

The screening assay for VOCs, when applied on air samples taken in the scope of industrial and occupational hygiene monitoring practices, will generate results of airborne concentrations of the contaminants identified generally expressed in mg/m³. This reporting limit can be lowered to less than 1/100 of the assigned Threshold Limit Value (TLV) of a specific compound, provided that an adequately high volume of air is sampled (more details are given in **Annex 2**.)

The VOC-screening assay is also applicable to air samples taken in the scope of general area or environmental monitoring. The concentrations of the contaminants identified will then be reported in µg/m³. In order to achieve this lower quantification and reporting limit, an adequately high volume of air (> 100L) must be sampled.

Sampling on activated charcoal tubes, the VOC-analysis always involves extensive qualitative and quantitative screening on both sections of the tube.

Concentrations of components in product analysis reports are given in weight or volume percentages.

The screening assay for VOCs is based on integrated validated analyzing methods as published by NIOSH, OSHA and EPA (see also **Annex 2**).

Analytical data generated during the screening assay for VOCs can additionally be transformed into a semi-quantitative determination of total airborne hydrocarbon concentrations. Total hydrocarbon concentrations will be calculated by means of average conversion and calculation factors depending on the nature of the hydrocarbon compounds.

Determination of total hydrocarbon content is available on request for the same price as charged for a corresponding VOC analysis. Determination of total hydrocarbon content can also be requested supplementary to a VOC analysis, for a low additional cost.

11.2. DUST AND METAL ANALYSIS

Sampling to define the inhalable dust fraction is performed with an IOM-sampler containing an IOM-cassette fitted with a PVC-filter, pre-weighted in the laboratory. After sampling, the filter unit will be reweighted. Sampling with an IOM-sampler requires an airflow of **2 L/min**. The total sampling volume required is at least **200 L**. Sampling to define the respirable dust fraction is performed by a cyclone containing a cyclone cassette with PVC-filter, pre-weighted in the laboratory. The required air sampling flow is specific for the combination of cyclone and filter (Higgins Dewell type cyclone of JS Holdings **2.2 L/min**).

Sampling for metals is performed on a MCE filter, placed in an IOM cassette (inhalable fraction) or in a cyclone cassette (respirable fraction). A list of possible metal determinations can be found on page 7.

11.3. GC-MS ANALYSIS

The laboratory uses the Gas chromatograph-Mass spectrometric method (GC-MS) for the semi-quantitative screening of organic compounds in an air sample and for product identification. This GC-MS analysis covers the range of very volatile (cfr. list of VOC-analysis compounds) to semi-volatile compounds (molecular weight comparable to that of higher polycyclic aromatic hydrocarbons). GC-MS analysis can be performed in addition to VOC analysis. For more information on this analysis, please contact the laboratory.

11.4. MINERAL OIL MIST ANALYSIS

To measure vapor and mist of mineral oil, the laboratory uses a glass fiber filter in combination with an active charcoal tube. The components on both media are analysed with GC-FID. This method is more specific and more sensitive than IR-spectrometrics. However, not all oils are suitable for gas chromatographic analysis. It is therefore strongly recommended to send a sample of the pure oil for testing, before air samples are taken. The oil is then tested for several specific parameters such as concentration range, linearity and detection limit. The test sample should be pure oil, not a solution or emulsion.

11.5. PHARMACEUTICAL COMPOUNDS (API / IPI)

The laboratory has several measuring methods for the determination of Active Pharmaceutical Ingredients (API) and Isolated Process Intermediate products (IPI) in the air. For a few APIs, determination methods in fluids (urine, plasma) are also possible. Most of the methods have been developed and extensively validated at the laboratory.

The list of APIs and IPIs that can be analysed at the laboratory can be found on page 9. The list further specifies measurements such as filter type, recommended pump flow, analysis procedure and price per analysis.

11.6. OTHER ANALYSES

For compounds that are not on the list of the VOC-analysis, a more specific measuring and analysis procedure is recommended in most of the cases. Please consult the "List of analyses – fees 2021" on page 5 for all the available analyses. It also provides more specific information such as sampling medium, recommended pump flow, sampling time and sampling volume, analysis procedure and price per analysis. For strongly related compounds such as polycyclic aromatic hydrocarbons (PAH), a package fee is given. This fee includes analysis of all individual compounds in the package. Analysing one or a few compounds in the package is also possible, for a fee per compound. Please consult the list for more information.

For compounds not mentioned in the list, please contact the laboratory for further information on analysing options, fees, etc...

11.7. DEVELOPMENT AND VALIDATION OF NEW METHODS

On request, the laboratory can develop and validate a new measuring method for the determination of a VOC, an API or an IPI in the air (or in swabs). This development can be restricted or extended, according to the availability of a referential method and depending on the parameters which must be validated. Please contact the laboratory for a detailed quotation with an accurate description of all the scheduled activities.

Annex 1 : List of compounds (with CAS-number) determined in VOC-analysis

Hydrocarbons :

n-pentane [109-66-0] *
2-methylbutane [78-78-4]
2,3-dimethylbutane [79-29-8]
2-methylpentane [107-83-5] *
3-methylpentane [96-14-0] *
cyclopentane [287-92-3]
methylcyclopentane [96-37-7] *
n-hexane [110-54-3] *
cyclohexane [110-82-7] *
1-hexene [592-41-6]
cyclohexene [110-83-8]
n-heptane [142-82-5] *
2,2,3-tri-methylbutane [464-06-2]
2,2-dimethylpentane [590-35-2]
2,3-dimethylpentane [565-59-3]
2,4-dimethylpentane [108-08-7]
2-methylhexane [591-76-4]
3-methylhexane [589-34-4]
methylcyclohexane [108-87-2] *
n-octane [111-65-9] *
iso-octane [540-84-1] *
2,3,4-tri-methylpentane [565-75-3]
2,3-di-methylhexane [584-94-1]
3,4-di-methylhexane [583-48-2]
2,5-di-methylhexane [592-13-2]
2,2,5-tri-methylhexane [3522-94-9]
2-methylheptane [592-27-8]
3-methylheptane [589-81-1]
4-methylheptane [589-53-7]
n-nonane [111-84-2] *
4-methylnonane [17301-94-9]
n-decane [124-18-5] *
n-undecane [1120-21-4] *
n-dodecane [112-40-3] *
n-tridecane [629-50-5]
n-tetradecane [629-59-4]
n-pentadecane [629-62-9]
n-hexadecane [544-76-3]
limonene [5989-27-5] *
cis-decalin [493-01-6]
trans-decalin [493-02-7]

Glycol ethers and derivatives :

ethylene glycol monomethyl ether (2-methoxyethanol) [109-86-4] * ***
ethylene glycol monoethyl ether (2-ethoxyethanol) [110-80-5] * ***
ethylene glycol mono-iso-propyl ether (iso-propoxyethanol) [109-59-1]
ethylene glycol monopropyl ether (2-propoxyethanol) [2807-30-9]
ethylene glycol monobutyl ether (2-butoxyethanol) [111-76-2] * ***
ethylene glycol dimethyl ether (dimethylglycol) [110-71-4]
ethylene glycol diethyl ether (diethylglycol) [629-14-1]
ethylene glycol monomethyl ether acetate (methyl glycol acetate) [110-49-6]*
ethylene glycol monoethyl ether acetate (ethyl glycol acetate) [111-15-9] *
ethylene glycol monobutyl ether acetate (butyl glycol acetate) [112-07-2] *
ethylene glycol acetate [542-59-6]
ethylene glycol diacetate [111-55-7]
diethylene glycol diethyl ether (diethyl diglycol) [112-36-7]
propylene glycol monomethyl ether (1-methoxy-2-propanol) [107-98-2] *
propylene glycol monoethyl ether (1-ethoxy-2-propanol) [1569-02-4]
propylene glycol monomethyl ether acetate (1-methoxy-2-propanol acetate) [108-65-6]*
propylene glycol monoethyl ether acetate (1-ethoxy-2-propanol acetate) [98516-30-4]
ethylene glycol monohexylether (hexylcellosolve) [112-25-4]

Halogenated compounds :

methylene chloride [75-09-2] * **
chloroform [67-66-3] *
tetrachloromethane [56-23-5] *
1,1-dichloroethane [75-34-3]
1,2-dichloroethane [107-06-2] *
trans-1,2-dichloroethene [156-60-5]
cis-1,2-dichloroethene [156-59-2]
1,1,1-trichloroethane [71-55-6] *
1,1,2-trichloroethane [79-00-5]
1,1,2,2-tetrachloroethane [79-34-5]
pentachloroethane [76-01-7]
trichloroethylene [79-01-6] *
tetrachloroethylene [127-18-4] *
iso-propylchloride [75-29-6]
1,2,3-trichloropropane [96-18-4]

mono-chlorobenzene [108-90-7] *
benzylchloride [100-44-7]
benzylidenechloride [98-87-3]
p-dichlorobenzene [106-46-7] *
o-dichlorobenzene [95-50-1]
m-dichlorobenzene [541-73-1]
1,2,3-trichlorobenzene [87-61-6]

1,2-dibromoethane [106-93-4]
1-bromo-3-chloropropane [109-70-6]
2-bromoethylbenzene [103-63-9]
1-bromo-4-fluorobenzene (460-00-4)
methyl iodide [74-88-4]

Alcohols :

ethanol [64-17-5] *
n-propanol [71-23-8]
iso-propanol [67-63-0] *
1-butanol [71-36-3] *
2-butanol [78-92-2] *
iso-butanol [78-83-1] *
tert-butanol [75-65-0] *
3-pentanol [584-02-1]
iso-amyl alcohol [123-51-3]
tert-amyl alcohol [75-85-4]
cyclohexanol [108-93-0] *
methyl-iso-butylcarbinol [108-11-2]
benzylalcohol [100-51-6] *
allylalcohol [107-18-6]

Ethers :

diethylether [60-29-7] *
di-iso-propylether [108-20-3]
tert-butylmethylether [1634-04-4] *
dibutylether [142-96-1]

Miscellaneous :

tetrahydrofuran [109-99-9] *
2-methyltetrahydrofuran [96-47-9]
1,4-dioxane [123-91-1] *
acetonitrile [75-05-8] *
acrylonitrile [107-13-1] *
gamma-butyrolactone [96-48-0]
linalool [78-70-6]

Ketones :

acetone [67-64-1] *
methyl ethyl ketone [78-93-3] *
methyl-n-butyl ketone [591-78-6]
methyl-iso-butyl ketone [108-10-1]*
methyl-iso-amyl ketone [110-12-3]
ethyl-n-pentyl ketone [106-68-3]
di-n-propyl ketone [123-19-3]
di-iso-propyl ketone [565-80-0]
di-iso-butyl ketone [108-83-8]
cyclohexanone [108-94-1] *
isophorone [78-59-1]
mesityloxide [141-79-7]
diacetone alcohol [123-42-2] *
acetophenone [98-86-2]
1-methyl-2-pyrrolidone [872-50-4]
cyclopentanone [120-92-3]
2-methylcyclohexanone [583-60-8]
3-methylcyclohexanone [591-24-2]
4-methylcyclohexanone [589-92-4]

Esters :

methyl formate [107-31-3]
ethylformate [109-94-4]
n-propyl formate [110-74-7]
methyl acetate [79-20-9] *
ethyl acetate [141-78-6] *
vinyl acetate [108-05-4]
n-propyl acetate [109-60-4] *
iso-propyl acetate [108-21-4] *
n-butyl acetate [123-86-4] *

iso-butyl acetate [110-19-0] *
tert-butyl acetate [540-88-5]
n-amyl acetate [628-63-7] *
iso-amyl acetate [123-92-2]
benzyl acetate [140-11-4]
ethyl propionate [105-37-3]
n-propyl propionate [106-36-5]
methylbutyrate [623-42-7]
ethyl butyrate [105-54-4]
methyl acrylate [96-33-3]
ethyl acrylate [140-88-5]
butyl acrylate [141-32-2]
methyl methacrylate [80-62-6] *
ethyl methacrylate [97-63-2]
butyl methacrylate [97-88-1]
iso-butyl methacrylate [97-86-9]
dimethyl succinate [106-65-0]
dimethyl glutarate [1119-40-0]
dimethyl adipate [627-93-0]

Upon use of the **3M 3500 Organic Vapor Monitor** type, the compounds underlined can be quantified, as all essential calculation factors are made available by 3M®. For other compounds, some of these calculation factors are lacking for the adsorption-desorption system used and hence results are expressed in a semi-quantitative way (see Annex 2).

* Upon use of **Radiello Diffusive Samplers** (type 130 and 123-1), compounds listed with an asterisk (*) can be quantified, as all calculation factors are available. For other compounds, some of these calculation factors are lacking for the adsorption-desorption system used and hence results are expressed in a semi-quantitative way (see Annex 2).

** In the NIOSH 1005 method for methylene chloride, a limited total air volume of 2.5 L is recommended for a concentration of 1737 mg/m³ (500 ppm).

*** Upon use of activated charcoal tubes, results are expressed in a semi-quantitative way for these compounds (see Annex 2).

Annex 2 : Additional information concerning VOC-analysis

Analytical methodology:				
Test:	Measurement of volatile organic compounds (VOCs). Sampling has not been performed by the laboratory.			
Scope:	The VOC-analysis aims to identify and quantify organic solvents in air samples, taken on activated charcoal, in solvent mixtures or in viscous samples. The identity of compounds that can be determined in this analysis is listed in Annex 1. Each individual sample is assayed systematically for the presence or absence of the compounds listed in Annex 1. All identified compounds are subsequently quantified, provided that all essential calculation factors are available. Additional compounds (not listed in Annex 1) detected in the samples during the assay will be reported as non-identified compounds.			
Certification:	The Laboratory for Occupational and Environmental Hygiene has been granted formal accreditation according to the Belgian Royal Decree of 31 March 1992, for the measurement of 187 volatile organic compounds (listed in Annex 1) as detailed in the laboratory's sampling and analyzing method PM001_VOCs (formal certification published most recently on 6 December 2016).			
Reference methods:	NIOSH methods: 1500, 1501, 1552 1003, 1005, 1019, 1022 1300, 1301, 1400, 1401, 1402, 1403, 1450, 1454, 1457, 1458, 1459, 1602, 1604, 1609, 1615, 1618, 2500, 2508	aliphatic and aromatic hydrocarbons chlorinated hydrocarbons polar compounds		
Description:	<p>Prior to analysis, samples are extracted with an appropriate volume of carbon disulfide (CS₂). A small aliquot of each extract is analyzed using gas chromatography with flame ionisation detection (GC-FID). Each sample is injected simultaneously on two capillary analytical columns (60 m) with unique stationary phases. Organic compounds present in the sample are identified on the basis of a unique set of relative retention times (RRTs), specific for each product. Quantification of the identified compounds is based on a specific relative response factor (RRF) for each compound, a unique parameter determined and updated on a regular basis by validated laboratory tests. In the ultimate quantitative result, essential compound specific calculation factors (e.g. extraction recovery) and general sampling parameters (e.g. sampling volume) are incorporated.</p> <p>The CS₂ extraction recovery for each compound is pre-assayed in a relevant concentration range using a pre-defined type and lot of activated charcoal tubes (type NIOSH SKC 100/50 mg, Lot 2000 at present). These activated charcoal tubes can be purchased from the laboratory.</p>			
Provision:	<p>For samples taken on activated charcoal tubes, the reported airborne concentrations are based on the calculation factors determined by the laboratory for the pre-specified type of activated charcoal tubes (type NIOSH SKC 100/50 mg, Lot 2000 at present) and are valid subject to correctness of the sampling data and conditions communicated by the client.</p> <p>For samples taken on diffusion type monitors, the reported airborne concentrations are valid subject to correctness of the sampling data communicated by the client and subject to the availability and accuracy of all necessary calculation factors to be communicated by the manufacturer of the monitor.</p>			
Limit Values:	TLVs are the 2020 Threshold Limit Values published by ACGIH. GWs are the Belgian limit values (Royal Decree of January 12 2020).			
Reporting Limit:	<p>For occupational hygiene samples, the reporting limit of the assay is set at 1 mg/m³ -or 1/100 TLV for those compounds assigned a TLV below 100 mg/m³- provided that an air volume of at least 10L is sampled.</p> <p>Exceptions to this general reporting limit are specified as follows, again provided that an air volume of at least 10L is sampled: acrylonitrile (0,87 mg/m³), allyl alcohol (0,13 mg/m³), benzene (0,05 mg/m³), benzylchloride (0,07 mg/m³), chloroform (0,72 mg/m³), ethylacrylate (0,41 mg/m³), gamma-butyrolacton (1,3 mg/m³), methylacrylate (0,19 mg/m³), methylformate (1,5 mg/m³), methylglycolacetate (0,21 mg/m³), methyliodide (0,73 mg/m³), tetrachloromethane (1,3 mg/m³), 1,1,2,2-tetrachloroethane (0,29 mg/m³), 1,2,3-trichloropropane (0,17 mg/m³) and 1-methyl-2-pyrrolidone (2,9 mg/m³)</p> <p>For solvent mixtures or viscous samples, the reporting limit is set at 0,1% w/v or 0,1% w/w.</p>			
Detection Limit:	The pure analytical limit of detection is compound-specific, approximating < 0.5 - 5 µg per ml extract. An exception to this general limit of detection is the compound 1-methyl-2-pyrrolidone (29 µg/ml).			
Measurement uncertainty:	The global measurement uncertainty, including the error on the active sampling procedure –which is assumed to be one of the more significant errors in the global measurement protocol-, is estimated to be 10%. As a consequence, the pure analytical error is well below 10%.			
Ranges:	The assay result of compounds for which essential calculation factors are not available and, in addition, the results of non-identified compounds, are reported in a semi-quantitative way, indicated by the following ranges:			
	Code	Occupational Hygiene sample (>10L)	Environmental sample (>100L)	Solvent mixture or viscous sample
	-			< 1 % w/v of w/w
	+	< 1 mg/m ³ en > 1/100 TLV	< 1 µg/m ³	1 – 10 % w/v of w/w
	++	1 - 10 mg/m ³	1 - 10 µg/m ³	10 – 100 % w/v of w/w
	+++	10 - 100 mg/m ³ > 100 mg/m ³	10 - 100 µg/m ³ > 100 µg/m ³	
Validity:	<p>The analytical results reported following the above-mentioned assay, involve solely the sample object indicated in the respective report.</p> <p>This report should always be added, complete and indicating the original pagination, when further processing the analytical results.</p> <p>In the event of the assay of samples taken by the client or its representative, the laboratory holds sole responsibility for the accurate analysis of the samples provided.</p>			

Annex 3 : Package-analysis BTEXN and/or Package-analysis VOCl - List of compounds (with CAS-number) determined in VOCl analysis:

Package BTEXN :

benzene [71-43-2] *
toluene [108-88-3] *
ethylbenzene [100-41-4] *
m-xylene [108-38-3] *
p-xylene [106-42-3] *
o-xylene [95-47-6] *
naphtalene [91-20-3] *

Package VOCl :

methylene chloride [75-09-2] * **
chloroform [67-66-3] *
tetrachloromethane [56-23-5] *
1,1-dichloroethane [75-34-3]
1,2-dichloroethane [107-06-2] *
1,1,1-trichloroethane [71-55-6] *
1,1,2-trichloroethane [79-00-5]
trichloroethylene [79-01-6] *
tetrachloroethylene [127-18-4] *
trans-1,2-dichloroethene [156-60-5]
cis-1,2-dichloroethene [156-59-2]

Upon use of the **3M 3500 Organic Vapor Monitor** type, the compounds underlined can be quantified, as all essential calculation factors are made available by 3M ®. For other compounds, some of these calculation factors are lacking for the adsorption-desorption system used and hence results are expressed in a semi-quantitative way (see Annex 4).

* Upon use of **Radiello Diffusive Samplers** (RAD 130), compounds listed with an asterisk (*) can be quantified, as all calculation factors are available. For other compounds, some of these calculation factors are lacking for the adsorption-desorption system used and hence results are expressed in a semi-quantitative way (see Annex 4).

** In the NIOSH 1005 method for methylene chloride, a limited total air volume of 2.5 L is recommended for a concentration of 1737 mg/m³ (500 ppm).

Annex 4 : Package-analysis BTEXN and/or Package-analysis VOCl - Additional information

Analytical methodology:				
Test:	Package-analysis BTEXN and/or Package-analysis VOCl. Sampling has not been performed by the laboratory.			
Scope:	The VOC-analysis aims to identify and quantify organic solvents in air samples, taken on activated charcoal, in solvent mixtures or in viscous samples. The identity of compounds that can be determined in this analysis is listed in annex. Each individual sample is assayed systematically for the presence or absence of the compounds listed in annex. All identified compounds are subsequently quantified, provided that all essential calculation factors are available. Additional compounds (not listed in annex) detected in the samples during the assay will be reported as non-identified compounds.			
Certification:	The Laboratory for Occupational and Environmental Hygiene has been granted formal accreditation according to the Belgian Royal Decree of 31 March 1992, for the measurement of 187 volatile organic compounds (listed in Annex 1) as detailed in the laboratory's sampling and analyzing method PM001_VOCs (formal certification published most recently on 6 December 2016).			
Reference methods:	NIOSH methods: 1500, 1501, 1552 1003, 1005, 1019, 1022	aliphatic and aromatic hydrocarbons chlorinated hydrocarbons		
Description:	<p>Prior to analysis, samples are extracted with an appropriate volume of carbon disulfide (CS₂). A small aliquot of each extract is analyzed using gas chromatography with flame ionisation detection (GC-FID). Each sample is injected simultaneously on two capillary analytical columns (60 m) with unique stationary phases. Organic compounds present in the sample are identified on the basis of a unique set of relative retention times (RRTs), specific for each product. Quantification of the identified compounds is based on a specific relative response factor (RRF) for each compound, a unique parameter determined and updated on a regular basis by validated laboratory tests. In the ultimate quantitative result, essential compound specific calculation factors (e.g. extraction recovery) and general sampling parameters (e.g. sampling volume) are incorporated.</p> <p>The CS₂ extraction recovery for each compound is pre-assayed in a relevant concentration range using a pre-defined type and lot of activated charcoal tubes (type NIOSH SKC 100/50 mg, Lot 2000 at present). These activated charcoal tubes can be purchased from the laboratory.</p>			
Provision:	<p>For samples taken on activated charcoal tubes, the reported airborne concentrations are based on the calculation factors determined by the laboratory for the pre-specified type of activated charcoal tubes (type NIOSH SKC 100/50 mg, Lot 2000 at present) and are valid subject to correctness of the sampling data and conditions communicated by the client.</p> <p>For samples taken on diffusion type monitors, the reported airborne concentrations are valid subject to correctness of the sampling data communicated by the client and subject to the availability and accuracy of all necessary calculation factors to be communicated by the manufacturer of the monitor.</p>			
Limit Values:	TLVs are the 2020 Threshold Limit Values published by ACGIH. GWs are the Belgian limit values (Royal Decree of January 12 2020).			
Reporting Limit:	<p>For occupational hygiene samples, the reporting limit of the assay is set at 1 mg/m³ -or 1/100 TLV for those compounds assigned a TLV below 100 mg/m³- provided that an air volume of at least 10L is sampled.</p> <p>Exceptions to this general reporting limit are specified as follows, again provided that an air volume of at least 10L is sampled: benzene (0,05 mg/m³), chloroform (0,72 mg/m³) and tetrachloromethane (1,3 mg/m³).</p> <p>For solvent mixtures or viscous samples, the reporting limit is set at 0,1% w/v or 0,1% w/w.</p>			
Detection Limit:	The pure analytical limit of detection is compound-specific, approximating < 0.5 - 5 µg per ml extract.			
Measurement uncertainty:	The global measurement uncertainty, including the error on the active sampling procedure –which is assumed to be one of the more significant errors in the global measurement protocol-, is estimated to be 10%. As a consequence, the pure analytical error is well below 10%.			
Ranges:	The assay result of compounds for which essential calculation factors are not available and, in addition, the results of non-identified compounds, are reported in a semi-quantitative way, indicated by the following ranges:			
	Code	Occupational Hygiene sample (>10L)	Environmental sample (>100L)	Solvent mixture or viscous sample
	-	< 1 mg/m ³ en > 1/100 TLV	< 1 µg/m ³	< 1 % w/v of w/w
	+	1 - 10 mg/m ³	1 - 10 µg/m ³	1 – 10 % w/v of w/w
	++	10 - 100 mg/m ³	10 - 100 µg/m ³	10 – 100 % w/v of w/w
	+++	> 100 mg/m ³	> 100 µg/m ³	
Validity:	<p>The analytical results reported following the above-mentioned assay, involve solely the sample object indicated in the respective report. This report should always be added, complete and indicating the original pagination, when further processing the analytical results. In the event of the assay of samples taken by the client or its representative, the laboratory holds sole responsibility for the accurate analysis of the samples provided.</p>			

Annex 5 : Analysis request form for air- and product analysis



Environment and Health

Laboratory for Occupational and Environmental Hygiene

Kapucijnenvoer 35, 6th floor – box 7001

B-3000 Leuven (Belgium)

www.loeh.be

Tel: +32 16-37.32.81

Analysis request form for air- and product analysis

Data provided by the applicant

1. Identification details :

<u>Reporting data:</u>	<u>Invoice-data</u> ⁽¹⁾
Applicant (company):	Company/Service:
Contact person:	Contact person:
Address:	Address:
e-mail address:	e-mail address:
Tel:	Tel:
Y/ref (PO number):	

2. Type of analysis requested :

VOC-analysis ⁽²⁾: mg/m³ µg/m³

Dust ⁽²⁾: Metal ⁽²⁾:

Pharmaceutical compound (API / IPI) ⁽²⁾:

GC-MS-analysis ⁽²⁾:

Other analyses ⁽²⁾:

3. Information about the samples:

N° sample	Pump-n°.	Date	Volume (L)	Time (min)	Place	Expected compounds:

⁽¹⁾ Preferably, the invoice address is the same as the reporting address. If not, please specify.

⁽²⁾ Please specify if necessary.

⁽³⁾ Please do not specify **names of persons**, in view of the new European Privacy Law (GDPR) (Regulation (EU) 2016/679) regarding the privacy of the individual.

Annex 6: Closing days of the laboratory

Tuesday February 3, 2021 (KU Leuven Patron Saint's Day)

Monday April 5, 2021 (Easter Monday)

Thursday May 13, 2021 (Ascension Day)

Monday May 24, 2021 (Whit Monday)

Wednesday July 21, 2021 (National holiday)

Monday September 6, 2021 (Leuven Fair)

Monday November 1, 2021 (All Saints Day)

Tuesday November 2, 2021 (All Souls Day)

Thursday November 11, 2021 (Armistice)

Christmas holidays from Saturday December 25, 2021 till Friday December 31, 2021

DEPARTMENT OF
PUBLIC HEALTH AND PRIMARY CARE
ENVIRONMENT AND HEALTH
Laboratory for Occupational and Environmental Hygiene
Kapucijnenvoer 35, 6th floor box 7001
3000 LEUVEN, Belgium
tel. + 32 16 37 32 81

